

THE
SHARPER
IMAGE

ONE YEAR LIMITED WARRANTY

SI PRODUCTS sells its products with the intent that they are free of defects in manufacture and workmanship for the life of the original purchaser from the date of original purchase, except as noted below. SI PRODUCTS warrants that its products will be free of defects in material and workmanship under normal use and service. This warranty extends only to consumers and does not extend to Retailers.

To obtain warranty service on your SI PRODUCTS product, mail the product and your dated sales receipt (as proof of purchase), postpaid, to the following address:

SI PRODUCTS Consumer Relations
Service Center Dept. 168
3000 Pontiac Trail
Commerce Township, MI 48390
No COD's will be accepted.

SI PRODUCTS does not authorize anyone, including, but not limited to, Retailers, the subsequent consumer purchaser of the product from a Retailer or remote purchasers, to obligate SI PRODUCTS in any way beyond the terms set forth herein. This warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair; or any other conditions whatsoever that are beyond the control of SI PRODUCTS.

This warranty is effective only if the product is purchased and operated in the country in which the product is purchased. A product that requires modifications or adoption to enable it to operate in any other country than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under this warranty.

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY. SI PRODUCTS SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS WARRANTY REQUIRE MORE THAN THE REPAIR OR REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY.

NO REFUNDS WILL BE GIVEN. IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, SI PRODUCTS RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS IN LIEU OF REPAIR OR REPLACEMENT.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of SI PRODUCTS.

This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state. Because of individual regulations, some of the above limitations and exclusions may not apply to you.

For more information regarding our product line in the USA, please visit: www.siprducts.com

For service or repair - do not return this unit to the retailer.

Contact SI PRODUCTS Consumer Relations at 1-888-856-6781.

©The Sharper Image. All rights reserved. THE SHARPER IMAGE name and logo are registered trademarks.

THE
SHARPER
IMAGE

ULTRASONIC COOL MIST HUMIDIFIER



Instruction Manual and
Warranty Information

EV-HD15

1 year
limited warranty

Say goodbye to dry air forever.

Thank you for purchasing The Sharper Image® Ultrasonic Cool Mist Humidifier. This product, along with the entire The Sharper Image collection, connects high-tech innovation with cutting-edge design to provide you with years of dependability and enjoyment. The Ultrasonic Cool Mist Humidifier works silently to wipe out the discomfort of dry air while creating a fresh, pleasant environment, and looking its very best with any home or office décor.

IMPORTANT SAFEGUARDS

WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING

DANGER

- TO REDUCE THE RISK OF ELECTRIC SHOCK:

- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- DO NOT reach for an appliance that has fallen into water. Unplug it immediately.
- DO NOT use while bathing or in shower.
- DO NOT place or store appliance where it can fall or be pulled into a tub or sink.
- DO NOT place in or drop into water or other liquid.
- NEVER use pins or other metallic fasteners with this appliance.
- Keep dry - DO NOT operate in a wet or moist condition.
- DO NOT use water above 86° Fahrenheit

WARNING - TO REDUCE THE RISK OF BURNS, ELECTRIC SHOCK, FIRE OR INJURY TO PERSONS:

Caution: All servicing of this product must be performed by authorized SI Products Service Personnel only.

- An appliance should never be left unattended when plugged in. Unplug from outlet when not in use and before putting on or taking off parts or attachments.
- Close supervision is necessary when this appliance is used by, on or near children, invalids or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by The Sharper Image; specifically any attachments not provided with the unit.
- NEVER operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped, or dropped into water. Return it to SI Products Service Center for examination and repair.
- Keep cord away from heated surfaces.
- NEVER drop or insert any object into any opening.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- DO NOT operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock or injury to persons.
- DO NOT carry this appliance by the power cord or use cord as handle.
- To disconnect, turn all controls to the "off" position, then remove plug from outlet.
- This appliance is designed for personal, non-professional use only.
- DO NOT use outdoors.

SAVE THESE INSTRUCTIONS

Caution – Please read all instructions carefully before operating.

- Never leave the appliance unattended, especially if children are present.
- Never cover the appliance when it is in operation.
- This unit should not be used by children without adult supervision.
- Always keep the cord away from high temperature and fire.
- Do not lift, carry, hang, or pull the product by the power cord.

- If the adaptor sustains damage, you must stop using this product immediately and contact SI Products Service Center. (See the warranty section for SI Products address.)

Operation and Maintenance

- Do not repair or adjust the unit, the servicing must be performed by professional or qualified personnel.
- Do not operate any appliance with an aging, knotted or damaged cord or plug, the replacement must be performed by manufacture, service center or qualified professional personnel.
- Stop use if there is unusual noise or smell. Servicing should be performed by qualified personnel only.
- Humidifier should be unplugged when not in use for a long period of time.
- Do not touch the water in the main unit or the parts in the water when the unit is on.
- Never operate unit without water in the tank. Only use water in the tanks.
- Never add any additive to the water that is not produced or under the supervision of the manufacturer.
- Do not wash, adjust or move the humidifier without first unplugging the unit from its electrical outlet.
- For indoor use only. Keep the appliance out of reach from children. Do not allow children to use the appliance without supervision. For indoor use only. Keep the appliance out of reach from children. Do not allow children to use the appliance without supervision.

WARNING - TO REDUCE THE RISK OF INJURY:

- Always place the humidifier on a firm, flat, level surface.
- Please hold the water tank firmly with both hands when carrying full tank of water.
- Never place the humidifier in an area where it is accessible to children.
- Never use humidifier in an environment where explosive gases are present.
- Do not place the humidifier near heat sources, such as, a stove and do not expose the humidifier to the direct sunshine.
- Always place the unit in the normal temperature environment to avoid excess damage.
- Place the humidifier far away from furniture and home appliances.

- Perform regular maintenance of the Ultrasonic Nebulizer.
- Never put humidifier detergent in an area where it is accessible to children.
- Avoid contact of detergent to your mouth and eyes. If contact occurs, use clean water to wash immediately, if serious, contact poison control or seek medical treatment.
- Never use detergent to clean the ultrasonic nebulizer that is not recommended by the manufacturer.
- Never scrape the ultrasonic nebulizer with a hard object to clean.

Unique Features and Specifications

Ultrasonic Technology

This ultrasonic humidifier uses ultrasonic high frequency technology to convert the water into more than 1 million super particles that are dispersed into the air evenly. These particles then combine with the ions generated by the humidifier to moisten the air.

Night Light

A useful night light feature is included for your convenience.

Auto Shut Off Protection

When the tanks are empty the unit will shut off automatically.

Advanced Multi-Protection

The humidifier shuts off automatically if the water tank is removed OR unit is overloaded.

Ultrasonic Nebulizer and Radiator

Utilizes special spray techniques and the ultrasonic nebulizer and radiator is easy to clean for lifetime use.

Voltage

110-120 V / 60Hz

Watts


25

Tank Capacity

7 qt. total

Ultrasonic Cool Mist Humidifier

Fig. 1



How to Use

To reduce the risk of electric shock, this appliance is equipped with a plug (one blade wider than the other). This plug will only fit in a polarized outlet. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.




Fig. 2

Power Button

Plug unit in to a 120 volt AC electrical outlet. Push the POWER button to turn unit on. A green indicator light will be on.

ATTENTION: when the water in the water tank is almost empty the red indicator light will turn on and the power will shut off to indicate to the user to refill water.

Mist Adjustment Setting

To increase the mist output, turn the mist (☾) knob clockwise.

Night Light

Press the night light (✱) button to turn on the night light. The dial around the mist setting knob will light.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>