



12 Month Replacement Guarantee

We are so confident of the quality of our product, should this appliance develop any malfunction within 12 months of purchase (3 Months commercial use) due to faulty materials or manufacture, we will replace it for you absolutely free.

Sunbeam Service Centres

Sunbeam has established a network of authorised service centres throughout Australia and New Zealand to provide quick, convenient service for our customers.

Should your appliance require repair or service, either during or after the guarantee period, contact your nearest service centre.

For a complete list of Sunbeam's authorised service centres:

Australia

www.sunbeam.com.au/service centres
1800 025 059

New Zealand

www.sunbeam.co.nz/service centres
0800 786 232

Should you experience any difficulties with your appliance, please phone our free call customer service line for advice on 1800 025 059 in Australia, or 0800 786 232 in New Zealand. Alternatively, simply return the faulty appliance to your place of purchase, along with your purchase receipt. Your Sunbeam 12 Month Replacement Guarantee naturally does not cover misuse or negligent handling, and excludes breakables such as glass or ceramic items, and normal wear and tear. Similarly, your 12 Month Replacement Guarantee does not cover damage to household surfaces as a result of water or other substances leaking from your appliance, nor does it cover freight costs. In Australia, this guarantee is additional to the conditions and guarantees which are mandatory as implied under the Trade Practices Act 1974 and State and Territory legislation.



Therapeutics



Therapeutics Quilted Massager with Heat

Instruction Booklet
VB6500

Consumer Hotline

In Australia
Visit www.sunbeam.com.au
Or call 1800 025 059


In New Zealand
Visit www.sunbeam.co.nz
Or call 0800 786 232

 is a registered Trademark of Sunbeam.

Made in China.
Due to minor changes in design or otherwise,
the product may differ from the one shown in this leaflet.
© Copyright. Sunbeam Corporation Limited 2007.
ABN 45 000 006 771
Sunbeam Corporation is a division of GUD Holdings Ltd.

06/07





Features of your Quilted Massager with Heat

Using Your Quilted Massager with Heat

- Place the appliance on a suitable lounge or bed. The massager can also be used directly on the floor but the best results will be gained from use on a soft, comfortable surface and will result in quieter operation.
- Ensure that the appliance is switched off and then connect the adaptor output to the input jack.

Massage Options

- You can choose to massage one particular area of your body or choose to massage all areas together.
- Choose zone 1 to massage the neck and shoulders.
- Choose zone 2 to massage the back.
- Choose zone 3 to massage the thighs.

- Plug the adaptor plug into a suitable power outlet and switch on.
- Do not use for more than 20 minutes at a time.
- If discomfort occurs, discontinue use immediately.

- Choose zone 4 to massage the calves.
- Choose the heat option to apply soothing heat to the lower back. The LED light will come on when this setting is activated.
- There are 2 massage settings. Choose setting I for a relaxing massage and choose setting II for a more invigorating massage.

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR ALL ELECTRICAL APPLIANCES

Sunbeam are very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercises care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible adult to ensure that they can use the appliance safely.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven. Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- For safety reasons and to avoid maintenance by unskilled persons, some appliances are 'sealed' using tamperproof screws. Such appliances should always be returned to the nearest Sunbeam Appointed Service Centre for adjustment or repair if required.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been dropped or damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>