


# Fold<sup>N</sup>Go<sup>®</sup>

Care Center Lite

## Instruction Manual



**Do not use this product until  
you read and understand  
these instructions.**

English PM-1763AA 10/00

**Century**<sup>®</sup>

DEDICATED TO QUALITY

Read all instructions **BEFORE** assembly and **USE** of this product.

**KEEP INSTRUCTIONS FOR FUTURE USE.**

Store in pocket on bottom of floorboard.

## IMPORTANT INFORMATION

**This product can be used as a Playard,  
Bassinet, Changer or Sleeping Crib.**

### Table of Contents

#### Page:

#### 1 Important Information

#### 2 Warnings

#### 3 Assembly and Use

Playard/Crib

Bassinet

Changer

#### 7 Folding and Storing

Changer

Bassinet

Playard/Crib

#### 9 Maintenance

Cleaning

#### 9 Replacement Parts

### Need Help?

If you should have any problems with this product, **call toll-free 1-800-837-4044 from anywhere in the U.S. or Canada or fax at 1-610-286-4555.**

Or write us at: Century Products  
P.O. Box 100  
Elverson, PA 19520-9974  
Attention: Customer Service Department

Please have the following information available. See label on bottom tubing of Playard/Crib.

Model Number: \_\_\_\_\_

Manufacture Date: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

### Safety First Checklist

- ✓ Read and understand instruction manual before assembling and using *Fold'N Go® Care Center Lite*.
- ✓ Do not use in any vehicle.
- ✓ Always provide proper supervision for child's safety.
- ✓ Use with only one (1) child at a time.
- ✓ Do not use bassinet as a car bed.
- ✓ Do not use bassinet if infant can push up on hands and knees or sit unassisted.
- ✓ Do not carry bassinet with child in it.
- ✓ Do not move or fold Playard/Crib with child in it.
- ✓ Do not add padding or other objects inside Playard/Crib which may permit child to climb out or cause a suffocation hazard.
- ✓ Do not use accessories other than those provided by Century.

### Weight, Height and Activity Limits

Bassinet and Changer:

Maximum Weight: 8.2 kg (18 lbs.)

Maximum Height: 63.5 cm (25 inches)

Activity: Discontinue use if child can push up on hands and knees or sit unassisted.

Playard/Crib:

Maximum Weight: 14 kg (30 lbs.)

Maximum Height: 89 cm (35 inches)

Activity: Discontinue use if child can climb out of Playard/Crib.

***This product is NOT intended  
for commercial use.***




**WARNING** Failure to follow these warnings and the assembly instructions could result in serious injury or death.

- **When child is awake: NEVER leave child unattended. Always keep child in view.**  
**When child is sleeping: Always provide supervision necessary for the continued safety of child.**
- **Bassinet, Changer and Playard/Crib, including side rails, *MUST* be fully erected prior to use.**
- **Discontinue use of Playard/Crib when child reaches a height of 89 cm (35 inches), weighs more than 14 kg (30 lbs.), or is able to climb out.**
- **Use product with only one child at a time.**
- **SUFFOCATION HAZARD - To help prevent suffocation from entrapment, use only the floorboard provided by Century and always use attachment straps to secure floorboard to bottom of Playard/Crib. NEVER use additional mattress or padding.**
- **Strings can cause strangulation. DO NOT place items with a string around a child's neck (such as hood strings, pacifier cords, etc.). DO NOT suspend strings over product or attach strings to toys.**
- **DO NOT place product near a window where cords from blinds or drapes can strangle child.**
- **Keep product away from stoves, heaters, campfires, fireplaces and other hazards which can burn or cause injury to child.**
- **DO NOT add padding or objects inside Playard/Crib which may permit child to climb out.**
- **DO NOT move or fold Playard/Crib with child in it.**
- **DO NOT use product in a motor vehicle. Serious injury or death could result from a sudden stop or accident.**
- **DO NOT use a water mattress with this product.**
- **Before each usage, inspect product for damaged hardware, loose joints, missing parts or sharp edges. DO NOT use product if any parts are missing or broken. Call Century for replacement parts or instruction manual. DO NOT substitute parts.**
- **NEVER use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.**
- **If refinishing, use a non-toxic finish specified for children's products.**
- **DO NOT use accessories other than those provided by Century.**



**WARNING** Failure to follow these warnings and instructions could result in serious injury or death.


# ASSEMBLY and USE



- 4 Pull up on *Top Rails* until all "click" and lock.


**IMPORTANT:** Floor loop *MUST* remain raised at least 45.7 cm (18 inches) in order for rails to lock.

**NOTE:** Test by pushing down on each top rail to be sure they are locked.




## Playard/Crib

- 1 Unzip travel bag and remove Playard/Crib.



- 2 Stand Playard/Crib on legs and unfasten *Floorboard Attachment Straps*.



- 3 Separate Playard/Crib legs to approximately 60 cm (2 feet) apart.




**⚠ WARNING**


All top rails **MUST** be straight and locked in position or child may become entrapped and suffocate.

- 5 Push down on center of Playard/Crib floor until it is flat and *locks* into position.

**NOTE:** Locking action is automatic.




**HINT:** It may be necessary to lift end of Playard/Crib to push center down.



# ASSEMBLY and USE continued


- 6 Place floorboard in Playard/Crib with padded side facing up.



**NOTE:** *DO NOT* install floorboard if using bassinet. Go to bassinet assembly section.


- 7 Secure ends of floorboard to Playard/Crib:

- Pass *Attachment Straps* through holes in Playard/Crib floor.
- Secure straps to underside of Playard/Crib floor.



## **WARNING**

To prevent child from suffocating, attachment straps **MUST** be secured to underside of Playard/Crib.



**Playard/Crib assembly is now complete and ready to use.**


## Bassinet

### **WARNING**


Avoid serious injury or death:

- Use bassinet with infant who weighs less than 8.2 kg (18 lbs.) and is less than 63.5 cm (25 inches) tall.
- **DO NOT** use without floorboard being properly placed in bassinet.
- Discontinue use of bassinet if infant can push up on hands and knees or sit unassisted.
- **DO NOT** carry bassinet with infant in it.
- **DO NOT** use as a car bed.
- **SUFFOCATION HAZARD:** To help prevent suffocation from entrapment, use only floorboard provided by Century. **NEVER** use additional mattress or padding.


- 1 Lay bassinet on flat surface and spread open.




- 2 Rotate and extend four (4) *Hooks* until they "click" in place.



- 3 If floorboard is installed in Playard/Crib, remove floorboard.




- 4 Fold *Floorboard* into "W" shape and place in center of bassinet.






# ASSEMBLY and USE continued


- 5 Insert one side of floorboard under **Pocket** on side of bassinet.



- 6 Pull **Pocket** down over floorboard to hold floorboard in place.  
Repeat steps 5 and 6 for other side of floorboard.



- 7 Push down on center of floorboard to flatten.




## **Bassinet assembly is now complete.**

- Bassinet can be used *with* or *without* Playard/Crib.
- Bassinet can be used *with* or *without* changer.

## **To use bassinet with Playard/Crib:**


- 1 Place bassinet in Playard so that hooks go over long rails with "**T-Slots**" facing center of Playard.

**NOTE:** "**T-Slots**" **MUST** face center of Playard when using with changer.



- 2 Secure bassinet to Playard:

- Pass **Attachment Strap** through opening in corner of side panel of Playard.
- Fasten strap to outside of Playard.



Repeat for other strap.

## **Bassinet is now ready for use with Playard/Crib.**

## **To use bassinet without Playard/Crib:**



## **WARNING**

**Prevent falls and suffocation:**

- **Use only on a surface that is flat, level and stable.**
- **Keep bassinet away from surface edges.**

- 1 Set bassinet on flat and stable surface that will keep floorboard level so child will not roll into corner or side of bassinet resulting in breathing difficulties.
- 2 Keep at least 30.5 cm (12 inches) away from surface edges and stay within reach of child. Child's wiggling and rocking may cause bassinet to move and possibly fall off surfaces.

# ASSEMBLY and USE continued

## Changer


Changer can only be used when bassinet is installed in Playard/Crib.

### **WARNING**

Avoid serious injury or death:


- Always use restraint belt to prevent falls.
- Use with infant who weighs less than 8.2 kg (18 lbs.) and is less than 63.5 cm (25 inches) tall.
- Discontinue use of changer if infant can push up on hands and knees or sit unassisted.
- **DO NOT** carry changer with infant in it.

1 Lay changer on flat surface.




2 Grasp middle of each long side and gently pull apart until short sides "click" and lock in place.


**NOTE:** Make sure changer sides are fully extended and locked.



3 With vinyl side facing up, insert two (2) "T-Fittings" on changer into "T-Slots" in bassinet and push down to secure.




4 Push *Triangular Tabs* into *Triangular Holes* in Playard/Crib corners.



5 Secure changer to Playard/Crib:


- Pass *Attachment Strap* through opening in corner of side panel of Playard/Crib.
- Fasten strap to outside of Playard/Crib.

Repeat for other strap.



6 Place storage pocket flap over side of Playard/Crib.

**NOTE:** **DO NOT** place supplies weighing more than 2.3 kg (5 lbs.) in storage pocket.




**Changer is now ready for use.**

# FOLDING and STORING


## Changer

1 Unfasten both attachment straps.


2 Unhook "T-Fittings" from "T-Slots" by pulling up slightly on long side closest to bassinet, then pull changer away from bassinet.



3 Grasp short sides and feel for release buttons in center of short sides.




4 Press buttons on each side and push closed.




5 Place changer in pocket of travel bag.


3 Remove floorboard from bassinet.



4 Press release buttons on each hook and push hook into larger tube.



5 Rotate hooks to center of bassinet.



6 Fold bassinet.




7 Place bassinet in pocket of travel bag.

## Bassinet

1 Unfasten both attachment straps.

2 Remove bassinet from Playard/Crib.



**IMPORTANT:** If continuing to use Playard/Crib, be sure to properly secure floorboard in Playard/Crib.




# FOLDING and STORING

## Playard/Crib

1 To remove floorboard:

- Unfasten attachment straps.
- Remove floorboard and set aside.





2 To unlock and raise floor:

- Push down on center of Playard/Crib floor.
- Lift **Floor Handle** and rotate in direction of arrow (counterclockwise).
- Pull up on **Floor Handle** to raise floor.

Raise approximately 45.7 cm (18 inches).

**Floor Handle**





3 To fold top rails:

- Pull up on top rail slightly.
- Squeeze **Release Button** on bottom of top rail and push rail down. (Release buttons are identified by printed arrows.)

Repeat for other sides.


### NOTE:

- If rails are difficult to unlock, raise center of floor higher and squeeze **Release Button** again.
- If only one side of rail folds, squeeze **Release Button** again to fully fold.




4 Gather Playard/Crib frame together while pulling up on **Floor Loop**.

**Floor Loop**



5 Wrap floorboard around Playard/Crib frame with padding facing in.


**Handle**



6 Secure **Attachment Straps**:


- Bottom - Thread **Attachment Strap** through **Leg Loop** then through **Floorboard Loop** and fold back onto itself.
- Middle and Top - Thread **Attachment Straps** through remaining floorboard loops and fold back onto themselves.

**Attachment Straps**



**Floorboard Loop**

**Leg Loop**




7 Stand Playard/Crib on end and pull travel bag over Playard/Crib.

Be sure **Handle** comes through **Opening** in bag.

Turn over Playard/Crib and zip bag closed.

**Opening**

**Handle**



# MAINTENANCE

## Cleaning




### Playard/Crib, Bassinet, Changer and Floorboard

Surface wash with mild detergent and water, air dry.

### Travel Bag

Hand wash with warm water and mild detergent, drip dry.

## REPLACEMENT PARTS

Parts List (Model 10-749)	Price	Quantity	Total
<b>A. Travel Bag</b> 	US \$ 12.00 (CAN \$ 19.00)	x _____ =	\$ _____
<b>B. Padded Floorboard</b> 	US \$ 18.00 (CAN \$ 28.00)	x _____ =	\$ _____
<b>C. Instruction Manual</b> 	FREE	x _____ =	<u>FREE</u>

**NOTE:** Prices subject to change.

Total Parts \$ \_\_\_\_\_

# REPLACEMENT PARTS ORDER FORM

Total Parts \$ \_\_\_\_\_  
Sales Tax \$ \_\_\_\_\_  
Shipping & Handling \$ \_\_\_\_\_  
Outside Continental USA \$ \_\_\_\_\_  
Total \$ \_\_\_\_\_

## Sales Tax

- **California, Illinois, Indiana, Maryland and New York** Residents Add Sales & Applicable Local Taxes
- **Ohio** Residents Add 5.75% Sales Tax
- **Pennsylvania** Residents Add 6% Sales Tax except for **Philadelphia** and **Allegheny Counties** add 7% Sales Tax
- **South Carolina** Residents Add 5% Sales Tax

## Shipping & Handling

US \$ 0.01 to \$ 9.99 = US \$ 3.00  
(CAN \$ 0.01 to \$ 15.49 = CAN \$ 4.75)  
US \$ 10.00 and over = US \$ 5.00  
(CAN \$ 15.50 and over = CAN \$ 7.75)

## Outside Continental USA

Add: US \$ 10.00  
(CAN \$ 15.50)

*We must have this information to process your order: see label on bottom tubing of Playard/Crib.*

Model No.: \_\_\_\_\_

Manufacture Date: \_\_\_\_\_

Please make checks payable in US currency to **CENTURY PRODUCTS** or charge to VISA, MASTERCARD or DISCOVER.

Orders outside USA **Must** use credit card.

Cardholder's Name: \_\_\_\_\_

Card Number: \_\_\_\_\_

Card Exp. Date: \_\_\_\_\_

Check enclosed for \$ \_\_\_\_\_

**NOTE:** If requested color is not available, a similar color will be substituted.

## SHIP TO:

Name: \_\_\_\_\_

Address: \_\_\_\_\_

City: \_\_\_\_\_

State: \_\_\_\_\_ Zip: \_\_\_\_\_

Telephone No.:(\_\_\_\_\_) \_\_\_\_\_

**MAIL BOTH PAGES OF ORDER TO:**

**CENTURY PRODUCTS  
P.O. BOX 100  
ELVERSON, PA 19520-9974  
ATTENTION: CUSTOMER SERVICE DEPARTMENT  
or**

**FAX BOTH PAGES OF ORDER TO:**

**(610) 286-4555**

PM-1763AA 10/00



# Remember

We are here to help you!

**For immediate help, call our Customer Service Department at 1-800-837-4044 from anywhere in the U.S. or Canada or fax at 1-610-286-4555.**



Century Products  
Graco Children's Products Inc.  
A Division of Newell Rubbermaid  
Macedonia, Ohio 44056-2096

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>